



MAXIMUM SUPPRESSOR DIAMETER SHOULD NOT EXCEED 1.850".

TO MOCKUP AND ANTICIPATE OUR HANDGUARDS ABILITY TO SHROUD SUPPRESSORS IN LENGTH, USE A STRAIGHT RULE OR TAPE TO MEASURE FROM THE FRONT SURFACE OF YOUR UPPER RECEIVER FORWARD AS NOTED ON THIS PAGE. DIMENSIONS SHOWN ARE ACTUAL AND TRUE TO FORM.